



USER MANUAL ADBLUE EMULATOR FOR BOBCAT

EURO 6



www.canbusemulator.com/en

+90 530 937 46 36

erenakarsubasi

The connection socket is the AdBlue tank socket.

Socket	Emulator
Purple / White ----->	White Cable (CAN H)
Purple ----->	Brown Cable (CAN L)
Black ----->	Black Cable (-)
Orange ----->	Red Cable (+)

NOTE: NOx sensors should be isolated by removing them. The emulator should be isolated so that it does not get water. This socket will not be plugged in again as it is mounted on the Adblue Tank socket.



